

FIG. 1

VENDORS

25A



The vendors folder has numerous icons that access equipment that is common in the field.
Follow the instructions in the beginning of this Job Aid before attaching you computer to any equipment.

To access this equipment:

25B

13

11



1. Shut down programs
2. Connect to A/C power supply.
3. Connect an appropriate serial cable from the computer to the piece of equipment.
4. From the Main Desktop double click the Communications Menu.
5. From the Communications Menu double click the Vendors folder.
6. Select the appropriate icon for the equipment.
7. Double click the icon.
8. Depress the "Enter" key several times (the only exception is when connected to the HDSL depress the "Space Bar" several times).

You will be connected to the selected equipment.



Communications Menu

This will reveal the following window.



25A

FIG. 2A

25C

FIG. 2B

11
13
14
15

DDM2000



Follow the instruction at the beginning of this Job Aid before attaching your computer to any equipment.

To access the Lucent software:

1. Shut down programs.
2. Connect to A/C power.
3. From the Main Desktop double click on the DDM2000 folder.
4. Connect a serial cable from the serial port on the back of the computer to the interface on the Multiplexer.
5. Choose the appropriate type and version of software according to the Multiplexer.
6. Double click on the icon.
7. Depress the "Enter" key until a login prompt appears.
8. Login

This Folder has several versions of Lucent multiplexers provisioning software, including OC3's and OC12's.




FIG. 2B

[illegible]

Choose View, Toolbar to display a toolbar for use in the My Computer window. You can use this toolbar to navigate through the hierarchy and drives to which you have access. In addition, you have options that enable you to display the contents of your disk drives differently, depending upon your needs and preferences. For example, you can use the Small Icons option to display more icons on the screen, and you can use the Details option to display information about files, including file type and file size.



FIG. 3

29A

BOSIP

29B

1. Use the instructions under to dial into BOSIP.
2. From the Main Desktop double click the Communications Menu.
3. From the Communications Menu, double click the LMOS icon. The following will be displayed.
4. From the toolbar click on "Connect".
5. Choose a connection. The Telnet window will appear.




FIG. 4




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11